

Transforming an old fashioned shower with a stainless steel shower tray and a big sill and Hardy's-wall linings

into a modern tiled Step-in shower



This shower-NOT suitable for elderly people!

1. Gutting the whole unit.

2. 25 mm deep criss-cross cutting.



3. Breaking out the little cubes-very easy!

4. Smoothing the surface.

5. Waterproofing the walls & corners.



6. Fixing down the 10mm base.



7. Leveling in the base.



8. Waterproofing last corners & waste.



9. Tiling the walls first.



10. Tiling floor then grouting & silconing.



11. Finished step-in shower!