

Pre-tiled designer shower kit



Typical situation at any bathroom.



Carrying in the shower base and marking the hole for the drain pipe, drilling the hole, putting down the glue and positioning down the shower base

Fixing the waterproofing membrane to the



Fixing the wall panels to the studs by gluing and screwing. Using polyurethane glue and big head screws.



A piece of PVC pipe and poly-glue hold the main panel in place with the shower base. Sliding the brass wall-attachment over the cold and hot water outlets and screw it to the wall. Put the head shower panel in place by using poly-glue...



...and tightening all nuts between panel-panel and panel-wall. Secure the wall panel with stainless steel screws to the brass-wall-attachment.



Before sliding in the glass panels into the slots on base and panel, fill the slots half way with clear silicone. Put in another bead of clear silicone into the corner between glass and tile as soon the glass panel is inserted. Close all construction joints with silicone at the right color and after curing fill the tile joints on the wall with Flex-grout.

After cleaning and polishing –job done.

Detail

Slot for glass panels.



Detail

integrated
Leak control
flange by
ALLPROOF



shower installed, ready to be grouted