

**Installing a big shower base 1200x2500 mm with an up-stand onto existing wooden floor**



1. Sealing corner with sealing tape  
and waterproofing membrane



2. Waterproofing walls with  
waterproofing membrane



3. Getting the shower base and...



4. Putting the glue down the floor....



5. fixing the base to the floor with additional big haed nails and sealing the corner between wall and base with sealing tape and waterproofing membrane



6. Tiling the base and up-stand



7. Grouting and silconing joints and corners



8. Installing mixer and screen-finished job !