

Shower Base with up-stand on wooden floor

Construction

- 1- Timber wall construction with wall linings
- 2- Flooring board 22mm
- 3- Timber floor construction

Shower Base Components

- 6- Shower Base 20mm with up-stand, fixed to timber floor with solvent-free contact adhesive
- 7- ALLPROOF Leak Control Flange, rebated into flooring board
- 8- Riser & waste grate

Sealing & Waterproofing Components

- 9- Sealing tape, flexible
- 10- Waterproofing membrane
- 11- Silicone Sealant, applied before grouting

Tile Coverage

- 12- Floor tiles on flexible tile adhesive & flexible grout
- 13- Wall tiles on flexible tile adhesive & flexible grout

